

Brand	Type	CAN-bus data available from software	Plug-Play harness	Universal harness	CAN connection point/ NOTE	Photo
Alfa	147 <2002			190-500225W		
Alfa	147 2002>		190-5002110			<u>2</u>
Alfa	156 <2002			190-500225W		
Alfa	156 2002>		190-5002110			<u>2</u>
Alfa	156 Crosswagon		190-5002110			<u>2</u>
Alfa	159		190-5002130			<u>3</u>
Alfa	Brera		190-5002130			<u>3</u>
Alfa	GT		190-5002110			<u>2</u>
Alfa	Mito		190-5002130			<u>3</u>
Alfa	Spider 2007>		190-5002130			<u>3</u>
Alfa						
Audi	A2		190-5002230			<u>7</u>
Audi	A2 1.2TDI, 1.4TDI		190-5000310			<u>7</u>
Audi	A3 <2005		190-5002230			<u>7</u>
Audi	A3 TDI <2005		190-5000310			<u>7</u>
Audi	A3 2005>		190-5002450			<u>10</u>
Audi	A4 2001-2007		190-5002230			<u>7</u>
Audi	A4 1.9&2.5 TDI 2001- 2007		190-5000310			<u>7</u>
Audi	A4 2008>		190-5002450			
Audi	A5		190-5002450			
Audi	A6 <2006		190-5002230			<u>7</u>
Audi	A6 1.9&2.5 TDI <2006		190-5000310			<u>7</u>
Audi	A6 2006>		190-5002450			<u>10</u>
Audi	Q7		190-5002230			<u>7</u>
Audi	Q7		190-5002230			<u>7</u>
Audi	TT 2006>		190-5002450			<u>10</u>
Audi	R8		190-5002450			
Audi						
BMW	1-series (E87) 2004>			190-500225W		<u>18</u>

BMW	3-series (E90) 2005>			190-500225W		<u>18</u>
BMW	5-series (E60- E61) 2003>			190-500225W		<u>18</u>
BMW	6-series (E63- E64) 2004>			190-500225W		<u>18</u>
BMW	7-series (E65) 2001>			190-500225W		<u>18</u>
BMW						
Cadillac	BLS		190-5002130			<u>3</u>
Chevrolet	Aveo		190-5002400			<u>2</u>
Chevrolet	Captiva 2.0 VCDI		190-5002390			<u>20</u>
Chevrolet	Captiva 2.4 4WD		190-5002390			<u>20</u>
Chevrolet	Cruze LT 2009-		190-5002130			<u>3</u>
Chevrolet	Epica VCDI			190-500225W		<u>2</u>
Chevrolet	HHR		190-5002130			<u>3</u>
Chevrolet	Lacetti		190-5002400			<u>2</u>
Chevrolet	Nubira TCDI		190-5002400			<u>2</u>
Chevrolet						
Chrysler	PT Cruiser			190-500225W		<u>19</u>
Chrysler	Sebring		190-5000360			<u>6</u>
Chrysler	Voyager CRD 2006 - 2007			190-500034W		<u>24</u>
Chrysler	Grand Voyager 2008>			190-500225W		<u>25</u>
Chrysler						
Citroen	Berlingo <2006			190-500090		<u>8</u>
Citroen	Berlingo 2006- 2008		190-5000170			<u>16</u>
Citroen	Berlingo 2009>	F17.04T	190-5000410		DLC	<u>16</u>
Citroen	C1		190-5000090			<u>16</u>
Citroen	C1 Petrol		190-5000220			<u>11</u>
Citroen	C2 <2006		190-5000090			<u>1</u>
Citroen	C2 2006>		190-5000170			<u>16</u>
Citroen	C3 <2006		190-5000090			<u>1</u>
Citroen	C3 2006-2008		190-5000170			<u>16</u>
Citroen	C3 2009>		190-5000410			

Citroen	C4 <2008		190-5000090			<u>1</u>
Citroen	C4 Picasso <2008		190-5000170			<u>16</u>
Citroen	C4 2009>		190-5000410			
Citroen	C4 Picasso 2009>		190-5000410			
Citroen	C5 <2005		190-5000090			<u>1</u>
Citroen	C5 2005-2007		190-5000170			<u>16</u>
Citroen	C5 2008>		190-5000170			
Citroen	C5 (first generation)			190-500090		<u>8</u>
Citroen	C8			190-500090		<u>8</u>
Citroen	C-Crosser		190-5000360			<u>6</u>
Citroen	Jumper <2006		190-5000230			<u>7</u>
Citroen	Jumper 2006>		190-5000110			<u>2</u>
Citroen	Jumpy <2008		190-5000170			<u>16</u>
Citroen	Jumpy 2009>		190-5000410			
Citroen	Nemo		190-5000110			<u>2</u>
Citroen	Picasso 2006>		190-5000170			<u>16</u>
Citroen	Xantia			190-500090		<u>8</u>
Citroen	Xsara			190-500090		<u>8</u>
Citroen	Xsara Picasso			190-500090		<u>8</u>
Dacia	Logan		190-5002140			<u>7</u>
Dacia	Sandero		190-5002140			<u>7</u>
Dacia						
Dodge	Avenger		190-5000360			<u>6</u>
Dodge	Caliber		190-5000360			<u>6</u>
Dodge	Journey		190-5000360			<u>6</u>
Dodge	Nitro			190-500225W		<u>25</u>
Dodge	Ram Van CRD 2006-2007			190-500034W		<u>24</u>
Dodge						
Ford	C-Max		190-5000330			
Ford	Fiesta 2002-2008		190-5002200			<u>9</u>
Ford	Fiesta TDCI 2009>	F17.05C	190-5000330		DLC	
Ford	Fiesta 2009>		190-5000330			

Ford	Focus 2004 - 2007	F17.05D	190-5000330		DLC	<u>22</u>
Ford	Focus 2008>		190-5000330			<u>22</u>
Ford	Focus USA 2008>			190-500225W		<u>25</u>
Ford	Fusion		190-5002200			<u>9</u>
Ford	Galaxy TDI <2006		190-5000310			<u>7</u>
Ford	Galaxy 2006>		190-5000330			<u>22</u>
Ford	Ka 2009>		190-5002380			<u>20</u>
Ford	Kuga		190-5000330			<u>22</u>
Ford	Mondeo 2007>		190-5000330			<u>22</u>
Ford	Ranger 2.5TD & 3.0TDCI 2007>		190-5002320			<u>23</u>
Ford	S-max 2006>		190-5000330			<u>22</u>
Ford	Tourneo Connect 2007>		190-5000330			<u>22</u>
Ford	Transit 2006>		190-5000330			<u>22</u>
Ford	Transit Connect 2007>	F17.04T	190-5000330		DLC	<u>22</u>
Fiat	500		190-5002380			<u>20</u>
Fiat	Bravo		190-5002110			<u>2</u>
Fiat	Croma 2005>		190-5002130			<u>3</u>
Fiat	Doblo		190-5002110			<u>2</u>
Fiat	Ducato <2006		190-5002230			<u>7</u>
Fiat	Ducato 2006>		190-5002110			<u>2</u>
Fiat	Fiorino 2008>		190-5002110			<u>2</u>
Fiat	Grande Punto		190-5002130			<u>3</u>
Fiat	Idea		190-5002110			<u>2</u>
Fiat	Marea 1999>			190-500225W		
Fiat	Multipla		190-5002110			<u>2</u>
Fiat	Panda 2006>		190-5002380			<u>20</u>
Fiat	Punto <2006		190-5002110			<u>2</u>

Fiat	Scudo <2007			190-500050W		<u>8</u>
Fiat	Scudo 2007-2008		190-5000170			<u>16</u>
Fiat	Scudo MY2009		190-5000410			
Fiat	Sedici		190-5002210			<u>13</u>
Fiat	Stilo 2001>		190-5002110			<u>2</u>
Fiat	Strada		190-5002110			<u>2</u>
Fiat	Ulysse <2005			190-500050W		<u>8</u>
Fiat	Ulysse 2.2 JTD 2006>		190-5000170			<u>16</u>
Honda	Accord 2006-2008			190-500225W		<u>14</u>
Honda	Accord 2008>		190-5002240			<u>17</u>
Honda	Civic <2006			190-500225W		<u>14</u>
Honda	Civic 2006>		190-5002240			<u>17</u>
Honda	Civic Hybrid		190-5002240			<u>17</u>
Honda	CRV 2007>		190-5002240			<u>17</u>
Honda	CRV <2006			190-500225W		<u>14</u>
Honda	Jazz 2002-2008			190-500225W		<u>15</u>
Honda	Jazz 2009>			190-500225W		<u>27</u>
Honda	Fit 2009>			190-500225W		<u>27</u>
Honda	Insight 2009	F17.04T		190-500225W	DLC	<u>27</u>
Honda	FRV			190-500225W		<u>14</u>
Hyundai	Accent		190-5002110			<u>2</u>
Hyundai	Elantra		190-5000100			<u>4</u>
Hyundai	Getz <2007		190-5000100			<u>4</u>
Hyundai	Getz 2008>		190-5002400			<u>2</u>
Hyundai	Grandeur		190-5000370			<u>6</u>
Hyundai	H1 / i800 2.5 CRDI		190-5000100			<u>4</u>
Hyundai	H1 / i800 2.5 CRDI		190-5002110			<u>2</u>
Hyundai	H200 CRDI		190-5002110			<u>2</u>
Hyundai	H300 / Satellite		190-5002110			<u>2</u>

Hyundai	I10		190-5002400			<u>2</u>
Hyundai	I20		190-5002400			<u>2</u>
Hyundai	I30		190-5002110			<u>2</u>
Hyundai	Matrix <2007		190-5000100			<u>4</u>
Hyundai	Matrix 2008>		190-5002110			<u>2</u>
Hyundai	Santa-Fe		190-5000100			<u>4</u>
Hyundai	Santa-Fe 2006>		190-5000370			<u>6</u>
Hyundai	Sonata 2.0 CRDI		190-5000370			<u>6</u>
Hyundai	Sonata 2.4		190-5000370			<u>6</u>
Hyundai	Terracan 2.9 CRDI		190-5002110			<u>2</u>
Hyundai	Terracan 2.9 CRDI		190-5000100			<u>4</u>
Hyundai	Trajet		190-5002110			<u>2</u>
Hyundai	Trajet		190-5000100			<u>4</u>
Hyundai	Tucson		190-5000100			<u>4</u>
Hyundai						
Iveco	Turbo Daily 2006		190-5002110			<u>2</u>
Jaguar	X-type					
Jeep	Cherokee 2.8 CRD			190-500225W		
Jeep	Cherokee 2008>			190-500225W		<u>25</u>
Jeep	Compass		190-5000360			<u>6</u>
Jeep	Patriot		190-5000360			<u>6</u>
Jeep	Wrangler 2008>			190-500225W		<u>25</u>
Kia	Carens <2005		190-5000100			<u>4</u>
Kia	Carens 2006>		190-5000370			<u>6</u>
Kia	Carnival <2005		190-5000100			<u>4</u>
Kia	Carnival 2005>		190-5002110			<u>2</u>
Kia	Carnival 2006>		190-5002110			<u>2</u>
Kia	Carnival 2006>		190-5002110			<u>2</u>
Kia	Cee'd 2006-2009	F17.05C	190-5002110	-	DLC	<u>2</u>
Kia	Cerato		190-5002110			<u>2</u>

Kia	Magentis 2006>		190-5000370			<u>6</u>
Kia	Picanto <2007		190-5000100			<u>4</u>
Kia	Picanto 2008>		190-5002110			<u>2</u>
Kia	Rio <2007		190-5002110			<u>2</u>
Kia	Rio 2007>		190-5002400			<u>4</u>
Kia	Soul		190-5002400			<u>4</u>
Kia	Sorento <2005		190-5000100			<u>4</u>
Kia	Sorento 2006-2009		190-5002110			<u>2</u>
Kia	Sorento 2009 >	F17.05C	190-5002460		DLC	
Kia	Sportage		190-5002110			<u>2</u>
Lancia	Delta 2008>		190-5002110			<u>2</u>
Lancia	Lybra 1.9 JTD		190-5002110			<u>2</u>
Lancia	Musa		190-5002110			<u>2</u>
Lancia	Ypsilon 2006>		190-5002380			<u>20</u>
Land Rover	Defender Td-4			190-500225W		
Land Rover	Discovery 2004>			190-500225W		
Land Rover	Freelander (1997-2003)			190-500225W		
Land Rover	Freelander Td-4 (2003-2006)		190-5002200			<u>9</u>
Land Rover	Freelander 2 (2007>)		190-5002330			<u>22</u>
Lexus	IS-200		190-5002210			
LDV	Maxus		190-5002230			<u>7</u>
Mahindra	Scorpio (GOA)		190-5002110			<u>2</u>
Mazda	2 <2007		190-5002200			<u>9</u>
Mazda	2 petrol 2007>		190-5002220			<u>11</u>
Mazda	2 Diesel 2008>		190-5002330			<u>22</u>
Mazda	3 CITD, MPS, 2,0 petrol		190-5002330			<u>22</u>
Mazda	5 CITD 2005>		190-5002210			<u>13</u>

Mazda	5 Petrol 2008>		190-5002330		<u>22</u>
Mazda	6 <2007		190-5002210		<u>13</u>
Mazda	6 2008>			190-500225W	<u>25</u>
Mazda	B2500		190-5002320		<u>23</u>
Mazda	BT-50 2.5TDI &3.0 CRDi		190-5002320		<u>23</u>
Mazda	CX7		190-5002220		<u>11</u>
Mazda	MPV		190-5002320		<u>23</u>
Mazda	MX5 2006>		190-5002210		<u>13</u>
Mazda	RX8		190-5002210		<u>13</u>
Mercedes	A Class			190-500225W	<u>18</u>
Mercedes	B Class			190-500225W	<u>18</u>
Mercedes	C-Class 2007>		190-5002440		<u>21</u>
Mercedes	Sprinter <2006			190-500225W	<u>11</u>
Mercedes	Sprinter 2006>		190-5002440		<u>21</u>
Mercedes	Vaneo			190-500225W	<u>18</u>
Mercedes	Viano		190-5002440		<u>21</u>
Mercedes	Vito <2006			190-500225W	<u>11</u>
Mercedes	Vito 2006>		190-5002440		<u>21</u>
Mini	Mini 2001>			190-500225W	<u>18</u>
Mitsubishi	Canter 2008>			190-500034W	
Mitsubishi	Carisma DI-D 2001>		190-5002140		
Mitsubishi	Colt (2005>)		190-5002130		<u>3</u>
Mitsubishi	Grandis 2.0 DI-D			190-500030W	<u>13</u>
Mitsubishi	Grandis 2.4 MPI			190-500030W	<u>13</u>
Mitsubishi	Lancer 2008>		190-5000360		<u>6</u>
Mitsubishi	L200 Model 2006		190-5002290		<u>13</u>
Mitsubishi	Outlander 2007>		190-5000360		<u>6</u>
Mitsubishi	Pajero <2006				
Mitsubishi	Pajero 2006>		190-5002290		<u>13</u>

Mitsubishi	Shogun 2006>		190-5002290			<u>13</u>
Mitsubishi	Space Star		190-5002140			
Nissan	Almera		190-5002130			<u>3</u>
Nissan	Almera 05> 1.5dCi		190-5002130			<u>3</u>
Nissan	Almera Tino		190-5002130			<u>3</u>
Nissan	Cabstar F24 2007>		190-5002180			<u>12</u>
Nissan	Cube		190-5002180			<u>12</u>
Nissan	Interstar	F17.05D	190-5002140		DLC	<u>7</u>
Nissan	Kubistar		190-5002140			<u>7</u>
Nissan	Kubistar 1.5 dCi		190-5002140			<u>7</u>
Nissan	Micra 03>		190-5002180			<u>12</u>
Nissan	Micra 03> 1.5 dCi		190-5002180			<u>12</u>
Nissan	Navara (King Cab)		190-5002130			<u>5</u>
Nissan	Navara (King Cab)		190-5002130			<u>5</u>
Nissan	Note		190-5002180			<u>12</u>
Nissan	Note 1.5 dCi		190-5002180			<u>12</u>
Nissan	NP300		190-5002130			
Nissan	Pathfinder		190-5002130			<u>5</u>
Nissan	Patrol 2007>		190-5002180			<u>12</u>
Nissan	Pixo	F17.05C	190-5002210		DLC	
Nissan	Primastar	F17.05D	190-5002140		DLC	<u>7</u>
Nissan	Primera		190-5002130			<u>3</u>
Nissan	QashQai 2007>		190-5002180			<u>12</u>
Nissan	Tiida	F17.04T	190-5002180		DLC	<u>12</u>
Nissan	X-trail <2007		190-5002120			<u>5</u>
Nissan	X-Trail 2007>		190-5002180			<u>12</u>
Nissan	350Z		190-5002120			<u>5</u>
Opel	Agila 2003-2007		190-5002130			<u>3</u>
Opel	Agila 2008>		190-5002210			<u>13</u>

Opel	Antara		190-5000390			<u>20</u>
Opel	Astra 1998-2004			190-500225W		
Opel	Astra 2004-2009		190-5002130			<u>3</u>
Opel	Astra 2010		?			
Opel	Combo 2006>		190-5002130			<u>3</u>
Opel	Corsa C & D		190-5002130			<u>3</u>
Opel	Corsa 2006>		190-5002130			<u>3</u>
Opel	Frontera			190-500225W		
Opel	Meriva		190-5002130			<u>3</u>
Opel	Movano	F17.05D	190-5002140		DLC	<u>7</u>
Opel	Tigra Twin-top		190-5002130			<u>3</u>
Opel	Tour		190-5002130			<u>3</u>
Opel	Vectra B		190-5002130			<u>3</u>
Opel	Vectra C		190-5002130			<u>3</u>
Opel	Vivaro 2006>	F17.05D	190-5002140		DLC	<u>7</u>
Opel	Vivaro <2006		190-5002140			<u>7</u>
Opel	Zafira <2005			190-500225W		
Opel	Zafira 2005>		190-5002130			<u>3</u>
Peugeot	107		190-5000090			<u>16</u>
Peugeot	107 Petrol 2008>		190-5000220			<u>11</u>
Peugeot	1007 (2005-2006)		190-5000090			<u>1</u>
Peugeot	1007 (2006>)		190-5000170			<u>16</u>
Peugeot	206 (first generation)			190-500090		<u>8</u>
Peugeot	206/SW/CC (2005-2006)		190-5000090			<u>1</u>
Peugeot	206 2006>		190-5000170			<u>16</u>
Peugeot	207 2006>		190-5000170			<u>16</u>
Peugeot	207 2008>		190-5000410			
Peugeot	306 HDI			190-500090		<u>8</u>
Peugeot	307 (first generation)			190-500090		<u>8</u>
Peugeot	307/SW/CC (2005-2006)		190-5000090			<u>1</u>
Peugeot	307 2006>		190-5000170			<u>16</u>

Peugeot	308 <2008		190-5000170		<u>16</u>
Peugeot	308 2009>		190-5000410		
Peugeot	4007		190-5000360		<u>6</u>
Peugeot	406 HDI			190-500090	<u>8</u>
Peugeot	407/SW/Coupe (2005-2006)		190-5000090		<u>1</u>
Peugeot	407/SW/Coupe 2006>		190-5000170		<u>16</u>
Peugeot	407 2008>		190-5000410		
Peugeot	806 HDI			190-500090	<u>8</u>
Peugeot	807			190-500090	<u>8</u>
Peugeot	807 2,0 2008>		190-5000170		<u>16</u>
Peugeot	Bipper		190-5000110		<u>2</u>
Peugeot	Boxer <2006		190-5000230		<u>7</u>
Peugeot	Boxer 2006>		190-5000110		<u>2</u>
Peugeot	Expert <2007			190-500090	<u>8</u>
Peugeot	Expert 2008>		190-5000410		
Peugeot	Partner (2005- 2006)			190-500090	<u>8</u>
Peugeot	Partner 2006- 2008		190-5000170		<u>16</u>
Peugeot	Partner 2009>		190-5000410		<u>16</u>
Porsche	911/997 <2008		190-5002230		<u>7</u>
Porsche	911 2008>			190-500225W	
Porsche	966 MY2000			190-500225W	
Porsche	Boxter			190-500225W	
Porsche	Boxter S			190-500225W	
Porsche	Cayenne		190-5002230		<u>7</u>
Renault	Avantime		190-5002140		<u>7</u>
Renault	Clio II		190-5002140		<u>7</u>
Renault	Clio II 1,5 dCi		190-5002140		<u>7</u>
Renault	Clio III 1.5dCi 2006>		190-5002180		<u>12</u>
Renault	Clio III 2006- 2008		190-5002180		<u>12</u>
Renault	Clio III 1.5dCi 105HP		190-5002180		<u>12</u>

Renault	Espace		190-5002140			<u>7</u>
Renault	Kangoo		190-5002140			<u>7</u>
Renault	Kangoo 1.5 dCI		190-5002140			<u>7</u>
Renault	Kangoo 2008>	F17.04T	190-5002180		DLC	<u>12</u>
Renault	Koleos		190-5002180			<u>12</u>
Renault	Laguna 01>		190-5002140			<u>7</u>
Renault	Laguna 2006>		190-5002180			<u>12</u>
Renault	Laguna 2008>		190-5002180			<u>12</u>
Renault	Master	F17.05D	190-5002140		DLC	<u>7</u>
Renault	Mégane 03>		190-5002180			<u>12</u>
Renault	Mégane 03> 1.5 dCI		190-5002180			<u>12</u>
Renault	Mégane 03> Automatic		190-5002180			<u>12</u>
Renault	Megane 1.5 DCI 105 HP		190-5002180			<u>12</u>
Renault	Modus		190-5002180			<u>12</u>
Renault	Modus 1.5 dCi		190-5002180			<u>12</u>
Renault	Scénic 1.5 dCI		190-5002180			<u>12</u>
Renault	Scénic 08-2003>		190-5002180			<u>12</u>
Renault	Scenic 1.5 DCI 105 HP		190-5002180			<u>12</u>
Renault	Trafic	F17.05D	190-5002140		DLC	<u>7</u>
Renault	Twingo 2006		190-5002140			<u>7</u>
Renault	Twingo 2007>		190-5002430			<u>12</u>
Renault	Vel Satis		190-5002140			<u>7</u>
Saab	9-3 2002>	F17.05C	190-5002130		DLC	<u>3</u>
Seat	Alhambra		190-5002230			<u>7</u>
Seat	Alhambra 1.9TDI		190-5000310			<u>7</u>
Seat	Altea 2004>>		190-5002450			<u>10</u>
Seat	Arosa 2002-2004		190-5002230			<u>7</u>
Seat	Arosa 1.4TDI 2002-2004		190-5000310			<u>7</u>
Seat	Cordoba		190-5002230			<u>7</u>

Seat	Cordoba 1.4TDI		190-5002450		<u>7</u>
Seat	Cordoba 1.9TDI		190-5000310		
Seat	Ibiza 2002-2008		190-5002230		<u>7</u>
Seat	Ibiza 1.4TDI, 1.9TDI 2002- 2008		190-5000310		<u>7</u>
Seat	Ibiza 2008>		190-5002230		<u>7</u>
Seat	Leon 2002-2006		190-5002230		<u>7</u>
Seat	Leon 1.9TDI 2002-2006		190-5000310		<u>7</u>
Seat	Leon 2006>		190-5002450		<u>10</u>
Seat	Toledo <2004		190-5002230		<u>7</u>
Seat	Toledo 1.9 TDI <2004		190-5000310		<u>7</u>
Seat	Toledo 2004>		190-5002450		<u>10</u>
Skoda	Fabia 2000-2006		190-5002230		<u>7</u>
Skoda	Fabia 1.4TDI, 1.9TDI 2000- 2006		190-5000310		<u>7</u>
Skoda	Fabia 2006>		190-5002230		<u>7</u>
Skoda	Fabia 1.4TDI, 1.9TDI 2006>		190-5000310		<u>7</u>
Skoda	Octavia <2004		190-5002230		<u>7</u>
Skoda	Octavia 1.9TDI <2004		190-5000310		<u>7</u>
Skoda	Octavia 2004>		190-5002450		<u>10</u>
Skoda	Roomster		190-5002230		<u>7</u>
Skoda	Roomster 1.4TDI, 1.9TDI		190-5000310		<u>7</u>
	Superb		190-5002450		<u>10</u>
Smart	ForFour		190-5002130		<u>3</u>
Smart	ForTwo <2007			190-500225W	<u>2</u>
Smart	ForTwo 2007>		190-5002440		<u>21</u>
Ssang Yong	Actyon A200 Xdi		190-5002110		<u>2</u>
Ssang Yong	Actyon A230		190-5002110		<u>2</u>
Ssang Yong	Kyron M200Xdi		190-5002110		<u>2</u>

Ssang Yong	Kyron M200Xdi *		190-5002110			<u>2</u>
Ssang Yong	Rexton 2006>		190-5002110			<u>2</u>
Ssang Yong	Rexton 230			190-500225W		18
Ssang Yong	Rexton 270		190-5002110			<u>2</u>
Ssang Yong	Rexton 270*		190-5002110			<u>2</u>
Ssang Yong	Rodius 270		190-5002110			<u>2</u>
Ssang Yong	Rodius 270*		190-5002110			<u>2</u>
Subaru	Forester 2.0		190-5002220			<u>11</u>
Subaru	Forester 2008>		190-5002220			<u>11</u>
Subaru	Impreza 1.5, 2.0 R		190-5002220			<u>11</u>
Subaru	Impreza 2.5 WRX		190-5002220			<u>11</u>
Subaru	Impreza (2007>)		190-5002220			<u>11</u>
Subaru	Legacy (Outback) 2003>			190-500225W		<u>13</u>
Suzuki	Alto		190-5002210			<u>13</u>
Suzuki	Alto 1.0 Automatic	F17.04T	190-5002210		DLC	<u>13</u>
Suzuki	Grand Vitara <2006			190-500050W		<u>8</u>
Suzuki	Grand Vitara 2006>		190-5002210			<u>13</u>
Suzuki	Ignis 1.3 Diesel		190-5002130			<u>3</u>
Suzuki	Jimny 1,5 DSL		190-5002460			<u>3</u>
Suzuki	Liana			190-500050W		<u>8</u>
Suzuki	Splash		190-5002210			<u>13</u>
Suzuki	New Swift Diesel <2008		190-5002130			<u>3</u>
Suzuki	New Swift Diesel MY2008		190-5002210			<u>13</u>
Suzuki	New Swift SPORT <2008		190-5002210			<u>13</u>
Suzuki	New Swift AMT <2008		190-5002210			<u>13</u>
Suzuki	New Swift Petrol MY2008	F17.04T	190-5002210		DLC	<u>13</u>

Suzuki	New Swift 1.5 Petrol Automatic MY2008	F17.04T	190-5002210		DLC	
Suzuki	SX4 1.6	F17.04T	190-5002210		DLC	<u>13</u>
Suzuki	Wagon R		190-5002130			<u>3</u>
Toyota	Avensis < 2008		190-5002120			<u>5</u>
Toyota	Avensis Verso < 2008		190-5002120			<u>5</u>
Toyota	Avensis 2009 >	F17.05D	190-5002220		DLC	<u>11</u>
Toyota	Aygo		190-5000090			1
Toyota	Aygo MMT 2006-2007		190-5002220			<u>11</u>
Toyota	Aygo Petrol 2008>		190-5002220			<u>11</u>
Toyota	Auris 2007>		190-5002220			<u>11</u>
Toyota	Camry		190-5002120			<u>5</u>
Toyota	Corolla <2007		190-5002120			<u>5</u>
Toyota	Corolla 2007>		190-5002220			<u>11</u>
Toyota	Corolla Verso	F17.05C	190-5002120		DLC	<u>5</u>
Toyota	Hi-ace		190-5002120			<u>5</u>
Toyota	Hi-lux		190-5002120			<u>5</u>
Toyota	IQ 1.4 D4D		190-5002220			<u>11</u>
Toyota	IQ 1.0 VVT-I		190-5002220			<u>11</u>
Toyota	Hi-lux 2005>		190-5002210			<u>13</u>
Toyota	Land Cruiser 90		190-5002120			<u>5</u>
Toyota	Land Cruiser 100 2005>		190-5002210			<u>13</u>
Toyota	Land Cruiser 120 2003>		190-5002210			<u>13</u>
Toyota	Land Cruiser 150 2010>		190-5002220			
Toyota	Land Cruiser Prado 2005>		190-5002210			<u>13</u>
Toyota	Prius 2005>		190-5002210			<u>13</u>
Toyota	Prius 2001-2004		190-5002120			<u>5</u>
Toyota	Previa 2000>		190-5002120			<u>5</u>
Toyota	Raider		190-5002210			<u>13</u>
Toyota	RAV4 <2006		190-5002120			<u>5</u>

Toyota	RAV4 2006>		190-5002220			<u>11</u>
Toyota	Sienna 2003>		190-5002210			
Toyota	Urban Cruiser		190-5002220			<u>11</u>
Toyota	Verso		190-5002220			<u>11</u>
Toyota	Yaris D4D <2006		190-5002120			<u>5</u>
Toyota	Yaris 2006>	F17.04T	190-5002220		DLC	<u>11</u>
Toyota	Yaris 1,0 (MMT) 2006>		190-5002220			<u>11</u>
Volkswagen	Bora		190-5002230			<u>7</u>
Volkswagen	Bora 1.9TDI		190-5000310			<u>7</u>
Volkswagen	Caddy 2004>		190-5002450			<u>10</u>
Volkswagen	Caravelle		190-5002230			<u>7</u>
Volkswagen	Caravelle 1.9 & 2,5 TDI		190-5000310		Under steering column green/white (CAN High), green (CAN Low)	<u>7</u>
Volkswagen	Crafter 06>	F17.05D	190-5002440			<u>21</u>
Volkswagen	EOS		190-5002450			<u>10</u>
Volkswagen	Fox 1.2, 1.4 2005>		190-5002230			<u>7</u>
Volkswagen	Golf 4		190-5002230			<u>7</u>
Volkswagen	Golf 4 1.9TDI <2003		190-5000310			<u>7</u>
Volkswagen	Golf 5 (Plus) 2003>		190-5002450			<u>10</u>
Volkswagen	Golf 6		190-5002450			<u>10</u>
Volkswagen	Jetta 2005>		190-5002450			<u>10</u>
Volkswagen	Multivan 2003>		190-5002230			<u>7</u>
Volkswagen	Multivan 1.9 & 2.5 TDI 2003-		190-5000310			<u>7</u>
Volkswagen	Passat 2000-2005		190-5002230			<u>7</u>
Volkswagen	Passat 1.9&2.5 TDI <2005		190-5000310			<u>7</u>

Volkswagen	Passat 2005>	F17.04T	190-5002450		Right-side under dashboard, orange/brown (CAN High), orange/black (CAN Low)	<u>10</u>
Volkswagen	Polo 5 + 6 1999-2005		190-5002230			<u>7</u>
Volkswagen	Polo 1.4TDI, 1.9TDI 1999-2005		190-5000310			<u>7</u>
Volkswagen	Polo 7 2005>		190-5002450			<u>10</u>
Volkswagen	Lupo		190-5002230			<u>7</u>
Volkswagen	Lupo 1.4TDI & 3L 1.2TDI		190-5000310			<u>7</u>
Volkswagen	Scirocco 2008>		190-5002450			<u>10</u>
Volkswagen	Sharan 2000>		190-5002230			<u>7</u>
Volkswagen	Sharan 1.9TDI 2000>		190-5000310			<u>7</u>
Volkswagen	Sharan 2.0 TDI 2000>		190-5002450			
Volkswagen	Tiguan		190-5002450			<u>10</u>
Volkswagen	Touareg 2002>		190-5002230			7
Volkswagen	Touran 2003-2006		190-5002230			<u>7</u>
Volkswagen	Touran 1.9TDI 2003-2006		190-5000310			<u>7</u>
Volkswagen	Touran 2006>		190-5002450			<u>10</u>
Volkswagen	Transporter 5		190-5002230			<u>7</u>
Volkswagen	Transporter 5 1.9 & 2,5 TDI		190-5000310			<u>7</u>
Volvo	C30	F17.04T	190-5000330		DLC	<u>22</u>
Volvo	S40		190-5000330			<u>22</u>
Volvo	V50		190-5000330			<u>22</u>
Volvo	C70		190-5000330			<u>22</u>
Volvo	V70 2007>		190-5000330			<u>22</u>
Volvo	XC70 2007>		190-5000330			<u>22</u>
Volvo	S80 2006>		190-5000330			22